



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70133

CHEVY / GMC TAHOE /

SUB / YUKON XL

2000 - 2004

ROLL PAN

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Roll Pan	1	Instruction Sheet		
2	1/4 X 3/4" Bolts	4	1/4" Flatwashers	2	1/4" Nyloc Nuts
6	# 10 Washerhead Self Drilling Phillips Head Screws				

TOOL LIST	
Ratchet, Sockets, Drill Motor, 1/4" Drill Bit, Phillips Screwdriver	

1. Remove the rear bumper, Remove all bumper brackets. If you are not sure how to do this, Installing a roll pan is not a job for you.
2. Set the roll pan into position. (Hint use masking tape to hold in place.) Check for fitment at bottom corners.
3. Fasten across the top using the self drilling phillips screws. Space them equally across.
4. From the underside of truck drill through the return edge of roll pan and into the body panel at the bottom side of roll pan.
5. Fasten at these points, using the 1/4 X 3/4" bolts & nuts provided.

NOTE:

We Highly recommend adding a cross bar across the back of the frame in front of the roll pan before installing roll pan.