



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70590  
1987 - 1993  
DODGE D-50  
FRONT VALANCE

### INSTALLATION INSTRUCTIONS

**NOTE: Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.**

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

#### PARTS LIST

1	Street Scene Valance	1	Instruction Sheet		
16	1/4" Flat Washers	8	1/4-20 X 3/4" Bolts	8	1/4-20 Nyloc Nuts

#### TOOL LIST

Ratchet, 7/16" Wrench, Drill Motor, 1/4" Drill Bit

1. Remove the OEM valance from truck.
2. Place the OEM valance and Street Scene valance mounting sides face to face.
3. Mark the hole location and drill a 1/4" hole.
4. Fasten the Street Scene valance with the screws provided.