



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70702
1997 - 2003
HOOD COWL
FORD F-150
&
EXPEDITION

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, prepped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

NOTE: DRILLING NECESSARY NOTE: NO CUTTING NECESSARY

PARTS LIST					
1	Hood Cowl	1	Instruction Sheet	2	Washer Head Sheet Metal Screws
2	Plastic Retainers	1	Street Scene Emblem		

TOOL LIST	
3/8" Ratchet, 3" Extension, Drill Motor, 1/8" Drill Bit, 15 MM Socket, Phillips Screwdriver Small Flat Blade Screwdriver, Safety Glasses	

1. Before beginning installation be sure to wear proper eye protection.
2. Mark location of the hood and remove.
3. Remove the wiper arms by first lifting off the plastic covers at arm base. Remove the 15 MM nuts securing the wiper arm assemblies.
4. Prying up with a small flat blade screwdriver, remove the 5/8" round plugs located at the right and left corners of the hood cowl. Remove the phillips head screws located underneath.
5. Remove the eight phillips head screws securing the hood cowl.
6. Remove the five "C" clips securing the hood cowl to the fire wall. Save to re-install.
7. Remove the plastic push-in retainers securing the hood cowl at each corner by prying up with a small flat blade screwdriver. Discard the retainers. New ones are provided in the installation kit.
8. Remove the rubber hood seal at forward edge of hood cowl by carefully prying up the eight fastening points. Discard
9. Install the new hood cowl by placing on the truck and inserting the push-in retainers at each corner.
10. Install the five "C" clips removed in step 6.
11. Open the doors. Carefully drill a 1/8" hole through hole in hood cowl and into the firewall, making sure the corners are held down in position before drilling.
12. Carefully secure hood cowl to the firewall with screws provided. Take caution not to scratch the doors and fenders.
13. Re-install the hood onto the truck.
14. Install the wiper arms and covers.
15. Paint to match.