



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
Costa Mesa, Ca. 92626  
Phone (714) 426-0590 Fax (714) 426-0591

950-70721  
1997 - 2003  
FORD F-150 SHORT / LONG BED  
SMOOTH TAILGATE CAP

### INSTALLATION INSTRUCTIONS

**NOTE: Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.**

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Smooth Tailgate Cover	1	Instruction Sheet	1	Street Scene Decal
10FT.	1/2" 2 Sided Tape	1	Urethane Prep Sheet		

TOOL LIST	
NONE	

#### NOTE:

**Check fitment of tailgate cap before painting, Sand edges to match tailgate width. Follow urethane painting instructions.**

1. Remove factory tail gate piece. Clean top edge of tailgate with alcohol.
2. Clean the back side of the smooth tailgate cap with alcohol and apply the two sided tape.
3. Set the smooth tailgate cap into position and remove the two sided tape while applying pressure to the part.