



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70765  
1986 - 1993  
MAZDA PICKUP  
FRONT VALANCE

### INSTALLATION INSTRUCTIONS

**NOTE:** Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Street Scene Valance	1	Instruction Sheet		
10	1/4-20 X 1" Bolts	1	Street Scene Emblem	5 FT.	1/2" wide 2 Sided Tape
20	1/4" Flat Washers	10	1/4" Nyloc Nuts		

TOOL LIST	
Drill Motor, Drill Bits, 7/16 Socket, Ratchet, 7/16" Wrench, Metric Sockets	

1. Remove the OEM valance from bumper.
2. Set the OEM valance on to the Street Scene valance, Mounting side to mounting side and mark mounting holes.
3. Attach with bolts provided ( **NOTE:** you may not require all the bolts in kit ). Use the furnished 2 sided when necessary on the sides of the valance.