



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70825
FRONT VALANCE
1999-2004
FORD F-250 & F-350
SUPER DUTY
& EXCURSION

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Front Valance	1	Instruction Sheet	7	# 14 S/S thruss Head Screws
2	# 10 S/S Screws	1	Street Scene Decal		

TOOL LIST	
Drill Motor, 2 - C Clamps (Helpful but not neccsary), 1/8" Drill Bit, Masking Tape, Phillips Screwdriver, Safety Glasses	

- 1 . Remove front bumper and OEM valance as an assemble.
2. Remove OEM valance from bumper.
3. Place the front valance under the bumper and clamp at each end. Align the front valance with the bumper edges. Tape valance to bumper to position and turn bumper over.
4. Carefully drill through the attachment holes on the bumper with the 1/8" drill into the solid areas on the Street Scene valance being carefull not to drill thru the valance. Valance is **NOT** returnable once drilled. Using the 7 S/S thruss head screws provided screw valance to bumper, **DO NOT OVER TIGHTEN** or you can strip the threads in the valance. At bumper corners drill thru bumper & valance and secure with the smaller S/S screws provided.
5. For a " SHOW " fit sand the top edge to fit the bumper.
6. Remove valance and paint to match.
7. Attach valance to bumper and install.

NOTE :

Speed Grille is available for valance Part Number is 950-77825