



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-72113
UNIVERSAL
FIBERGLASS
HOOD SCOOP
SPRINT CAR MEDIUM

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, prepped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Hood Scoop	1	Instruction Sheet	1	Fiberglass Paint Prep Sheet
		1	Street Scene Decal		

FOR OFF ROAD USE ONLY

Street Scene hood scoop are intended to fit fiberglass replacement hoods. How ever they may be use (Not recommended on factory steel hoods.) When being install by a trained fiberglass body repairman.

MOUNTING

Set hood scoop on top of hood to desired location. Check under side of hood for any obstructions. Measure to the right and left of scoop to center scoop in hood. Mark around the outside perimeter of scoop and remove. Draw a line 1 1/2" inward of perimeter mark. Cut out as needed. DO NOT remove any structural supports.

Fiberglass hood scoop to the fiberglass hood using fiberglass matt and resin. Install a layer of matt and resin over the top lip of scoop and hood. Fill as necessary " Duraglas " works well for this. Sand and prime. Fill all pin holes before painting. We highly recommend a professional fiberglass repair bodyman for this operation.