

STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue Costa Mesa, Ca. 92626 Phone (714) 426-0590 Fax (714) 426-0591 950-76714 BLACK CHROME 950-77714 SATIN FINISH 950-78714 CHROME FINISH 2007 FORD EXPEDITION SPEED GRILLE INSERTS

INSTALLATION INSTRUCTIONS

VERY IMPORTANT! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST						
1	Upper Grille Insert	1	Instruction Sheet	1	Center RT Grille Insert	
1	Lower Grille Insert	1	Street Scene Emblem	1	Center LT Grille Insert	
1	Care For Grilles			20	Installation Clips # 71098 3/4" Long	
				22	Installation Clips # 71099 1" Long	

TOOL LIST
1002 2131
Flat Blade Screwdriver, Phillips Screwdriver, #30 Torx Socket, Ratchet, Panel Removal Tool

- 1. Remove the eleven fasteners that secure the panel between the grille and core support by removing the center phillips head screw and then prying out the body. Remove panel.
- 2. Remove the push in fasteners attaching the rubber air shield to the grille at each end.
- 3. Reach in behind the front grille and pry off the four silver color clips connecting the grille shell to the fascia.
- **4.** Remove the four # 30 Torx fasteners across the top of grille and remove grille by pushing it forward to release it from the tabs on the bumper cover.
- **5.** Set the grille shell on a protective coverd table or bench.
- 6. Remove the Speed Grille inserts from the bags, each Speed Grille section is marked for it's location.
- 7. Install the Speed Grilles into the openings in the grille shell, the shorter side of each grille will face up.
- **8.** From the back side clip each Speed Grille to the grille shell. Look at the drawing below as a reference on installing clips. Use eight clips on each center Speed Grille section. Four on the top side and four on the bottom side. On the upper and lower Speed Grilles, Use twelve clips each six on the top and six on the bottom.
- **9.** Install Grille Shell back on vehicle by first inserting the bottom of grille into the tabs on the bumper cover and then installing the fasteners removed in step one and two.



71098 71099 71098